

# Can I move my PATGuard 2 licence to another PC?

It is possible to move the PATGuard 2 licence from one computer to another. Simply select Transfer... at the Login window to deactivate the original program.

- 1) The Transfer... button will change to Restore... to enable the licence to be re-activated.



- 2) Another computer with PATGuard 2 already installed will now be able to run the program. To return to the original computer, select Transfer... to deactivate the licence. At the original computer select Restore... to re-activate the licence and run the program.



**Note:**

The above Transfer process requires an internet connection. If an Internet connection is not available request a manual transfer by email to [transfer@seaward.co.uk](mailto:transfer@seaward.co.uk)