

How do I set up user tests in Apollo?

The Apollo 500 & 600 test instruments have the ability to add test sequences for other, non PAT related tests and inspections.

- 1) Please register your Apollo and you will receive an additional 12 months warranty plus full access to Product Support. Please do this at www.seaward.co.uk/warranty24
- 2) From the Apollo home screen  press the Menu button F4. 
- 3) In the menu select PAT Edit by pressing key number 4. 
- 4) This shows a list of all current test sequences. Press the menu button  to open up Test Sequence Options menu.
- 5) Select Add New using the arrow keys and the accept button. This will add a new sequence to the bottom of the list.
- 6) With the New Test Sequence highlighted press the menu button  to open up Test Sequence Options menu.
- 7) Select Edit using the arrow keys and the accept button. This will open up the test sequence for editing.
- 8) To edit the name of the sequence press the edit button . You can then give it a relevant name and press the save button to store .
- 9) Press the add test button  to add a test or inspection to the sequence. Use the arrow keys to select which test or inspection you would like to add from the list or select the user test option by pressing up once when at the beginning of the list.
- 10) If you select the user test option you will then need to give it a name from the dropdown or by free typing into the box.
- 11) You can then add the unit of what you would like to record if relevant and press the save  button to store.
- 12) Repeat steps 9-11 until you have added all of the required steps.
- 13) Once complete press the back button and then select yes by pressing the Y key when asked if you want to save changes.
- 14) If you wish to move the newly created test sequence up or down the list you can do this using the arrow keys on F2 & F4.
- 15) From the home screen select PAT  and then auto test . Your test sequence will be available from the menu.