





# How to Upload to your Apollo from PATGuard 3



The following document is intended to be a troubleshooting guide to ensure you are uploading to PATGuard 3 in the correct manner (note: you cannot upload to the Apollo 400). Please check all aspects of this before contacting the technical support helpline.


- 1) Please register your Apollo to receive an additional 12 months warranty plus full access to Product Support. You can do this at [www.seaward.co.uk/warranty24](http://www.seaward.co.uk/warranty24) or by completing the form in the “Care and Support” card and returning by post.
- 2) Please ensure your Apollo has the latest firmware installed, to do this please see the following link: [www.seaward.co.uk/apollo-series-firmware](http://www.seaward.co.uk/apollo-series-firmware)
- 3) Before attempting an upload we suggest you perform a download from your Apollo Series to PATGuard 3, as this will confirm your PATGuard 3 software / database is working correctly – see Application Note 0066 “How to Download the Apollo Series into PATGuard 3”.

- 4) On the Apollo “Home Screen”  select menu/options, function key “F4”. 
- 5) In the menu select “Upload” by using the arrow keys or selecting, key number “7”. 
- 6) In the “Upload data into Apollo” field select “From PATGuard 3”, using the arrow keys to select from the dropdown menu.
- 7) In the “using:-” field select  “USB-PC cable”. An additional Apollo drive (for example ApolloXXXX:) will appear on your PC. (Apollo 500 or 600)

or

In the “using:-” field select  “Flash Memory Stick” (Apollo 600 only)


- 8) In PATGuard 3, if you have not already, select “Instruments” and “Add Test Instrument” 
- 9) In “PAT Testing” , select the “Site” or “Location” you wish to upload.

- 10) Select the “Data Transfer” tab and “Upload to Tester” , select the “Destination” test instrument and correct drive (from the dropdowns – this will be either the ApolloXXXX: drive or Flash Memory Stick drive from step 7) - next select the Site & Location you want to upload including the data to be included (where applicable) - press “OK”.
- 11) A message saying – “File Saved Successfully : \ApolloUpload.gar” should appear on the PC

## Application Note 0067

- 12) On the Apollo the message “Save data to Apollo drive, press F3 when done” – select using the function key “F3”  . The following message will then appear on the Apollo “Valid Data files from PC. Select one of these files and press F4”. Select the file containing your uploaded data (/ApolloUpload.gar) , using the arrows keys, and save by selecting “F4”  (USB-PC cable, Apollo **500** or **600**)

or






After transferring the USB memory stick (you will receive a message if you have not done this), in the field below “Valid data files from USB memory stick. Select one of these files and press F4” - select the file containing your uploaded data (/ApolloUpload.gar), using the arrows keys, and save by selecting “F4”  (Flash Memory Stick, Apollo **600** only)

**Note:**

When selecting one from multiple files please ensure the correct file is highlight.

- 13) A message saying “SSS data uploaded OK” will be shown on the Apollo.

**Note:**

The uploaded data is displayed in a different location to the already tested data: On the Apollo “Home Screen”  select menu/options, function key “F4”  , select “View Data”, by selecting number “1”  and then the filter button by selecting “F2”  . In the “Select Tests” section select “Uploaded Data” using the blue arrow keys and accept using the function key “F3”  . In this new list all the uploaded data will be displayed.